

Instruction		Function
HEX	ASCII	
7F	DEL	Warm Reset
1B	ESC	About
58	X	Red LED on
59	Y	Red LED off
48	H	Green LED on
49	I	Green LED off
29)	Yellow LED on
28	(Yellow LED off
4A	J	Buzzer on
44	D	Arm to read
54	T	Read T1, Standard T1 Format
4B	K	Read T2, Standard T2 Format
5F	-	Read T3, Standard T3 Format
60	`	Arm to Write with RAW
64	d	Write T1, Standard T1 Format
65	e	Write T2, Standard T2 Format
66	f	Write T3, Standard T3 Format
67	g	Set Write Density for Specified Track
68	h	Set 210 BPI for T1&T3
69	i	Set 75 BPI for T1&T3
6A	j	Set 210 BPI for T2
6B	k	Set 75 BPI for T2
75	u	Set Coercivity High Only
76	v	Set Coercivity Low Only
70	p	Arm to Erase
77	w	Erase T1
78	x	Erase T2
7D	}	Erase T3
7E	~	Set Communication Baud Rate
39	9	Get firmware version

SparkFun Electronics 2008